

Temperaturgivare I852I



Givarhuvud för temperaturmätning med Mätman Combi.
NTC-givare $-35^{\circ}\dots+140^{\circ}\text{C}$ med 1 m kabel.

Vid leverans är givarhuvudet kalibrerat och justerat. Detta kan också göras av användaren med hjälp av mjukvaran **Mätman XL**. Justeringen lagras i givarhuvudet.

Tekniska data, givarhuvud I852I

Mätområde:	$-35^{\circ}\dots+140^{\circ}\text{C}$
Upplösning:	$0,1^{\circ}\text{C}$ vid $-35^{\circ}\dots+70^{\circ}\text{C}$ $0,5^{\circ}\text{C}$ vid $+71^{\circ}\dots+140^{\circ}\text{C}$
Mätnoggrannhet:	$\pm 1^{\circ}\text{C}$ vid $-35^{\circ}\dots+70^{\circ}\text{C}$ $\pm 2^{\circ}\text{C}$ vid $+71^{\circ}\dots+140^{\circ}\text{C}$
Mått:	$32\times 50\times 20\text{ mm}$ + 1 m kabel

Andra tillbehör till Mätman Combi

I8520	Temperaturgivare $-35^{\circ}\dots+70^{\circ}\text{C}$
I8522	Insticksgivare $-35^{\circ}\dots+140^{\circ}\text{C}$
I8540	$0-10\text{ V}/0-20\text{ mA}$
I8550	Spänning $0-2\text{ V AC}$
I8551	Strömtångsgivare $0-200\text{ A}$
I8552	Nätspänningsgivare för 230 V AC
3972	Mätpropphuv E27 för $0-25\text{ A}$
3973	Mätpropphuv E33 för $0-63\text{ A}$



ELTEX OF SWEDEN AB • BOX 24 • 283 21 OSBY • TEL 0479-53 63 00 • FAX 0479-53 63 99

info@eltex.se • www.eltex.se

2009-03-16/Manual I852I.pmd/EH-0213-04 /Komp 7914

Temperature sensor 1852 I



Sensor head for temperature measurement together with Mätman Combi. NTC sensor -35...+140°C with 1 m cable.

On delivery the sensor head is calibrated and adjusted. This can also be carried out by the user through the software **Mätman XL**. The adjustment is stored in the sensor head.

Technical data, sensor head 1852 I

Measuring range:	-35° ...+140°C
Resolution:	0,1°C vid -35° ...+70°C 0,5°C vid +71° ...+140°C
Accuracy:	±1°C vid -35° ...+70°C ±2°C vid +71° ...+140°C
Size:	32x50x20 mm + 1 m cable

Other sensors for Mätman Combi

18520	Temperature sensor -35...+70°C
18522	Penetration probe -35...+140°C
18540	0–10 V/0–20 mA
18550	Voltage 0–2 V AC
18551	Clip-on current sensor 0–200 A
18552	Net voltage sensor for 230 VAC
3972	Fuse cap E27 for current measurement 0–25 A
3973	Fuse cap E33 for current measurement 0–63 A

