



ELTEX ETM Solo Viewer

31020



The ETM Solo Viewer makes it possible to visualize yarn tension values from the ETM Solo sensors on a PC screen.

■ Applications

The ETM Solo viewer, together with the ETM Sensor, makes it possible to view and evaluate the tension of a yarn in a wide range of applications. Without such a device the yarn tension is often unknown but can have a big impact on the final product. For example, on a dyeing line where the tension is important for the final yarn colour, or a winder where the final bobbin quality depends on the thread tension.

Having the correct yarn tension does not only result in a high quality product but can also bring production and material cost down.

■ Features

- The ETM Solo Viewer shows the graphs for up to 16 ETM-Solo sensors at the same time.
- The graph of the sensors can also be selected in groups of four.
- When the graph is viewed for one sensor the digital value is presented as well.
- It is possible to zoom the graph and to scroll along the yarn tension axis.
- The sample time can be selected. The minimum sample time is depending on the performance of the computer, but is normally around 40 ms.
- The yarn tension values can be logged into a file which can be exported to Excel.
- At power up the software detects the number of sensors automatically.



■ The following parts are needed

- ETM Solo sensor(s)
- A PC computer
- 31020 ETM Solo viewer software
- 6883 CAN interface for the PC
- 65300 Modular cables
- 76620 Cable and power supply set
- 75015 Terminator for the CAN bus


■ System requirements for the computer

Hardware	Minimum	Recommended
Processor	Intel Pentium or compatible. Minimum 500 MHz clock frequency.	1 GHz clock frequency or higher.
Memory	Minimum 256 MB RAM	512 MB RAM or more.
Hard disk	Minimum 500 MB free space.	
Device	CD-ROM or DVD device.	
Screen	Screen and graphics card with SVGA (800 × 600) or better resolution.	

Compatible Operating system

- Windows 7
- Windows Vista
- Windows XP

■ The ETM Solo Viewer set up



ELTEX
OF SWEDEN

Box 24, SE-283 21 OSBY, Sweden | Tel: +46 479 536300 | Fax: +46 479 536399 | Email: info@eltex.se | www.eltex.se

Eltex U.S., Inc.
13031 E. Wade Hampton Blvd.,
GREER, South Carolina, 29651, USA
Tel: +1 864-879-2131
Fax: +1 864-879-3734
Email: sales@eltexus.com

Eltex Manufacturing Ltd.
Railway Road,
TEMPLEMORE, Co. Tipperary, Ireland
Tel: +353 504-314 33
Fax: +353 504-310 02
Email: info@eltex.ie

POLSA-ELTEX, S.L.
Zamora, 103 – entlo 3o,
ES-08018 BARCELONA, Spain
Tel: +34 93 309 00 17
Fax: +34 93 309 59 45
Email: polsa@infonegocio.com

Eltex China. Beijing S&S Electronics Technology Co., Ltd.
B052 F10, SOHO Nexus Center, No.19A,
East 3rd ring north Rd., Beijing, China 10020
Tel: +86 10 57351219
Fax: +86 10 65066468
Email: Chuan.Jiang@eltex.cn Web: www.eltex.cn