

Användarmanual för Mätman knapplogger

Mätman knapplogger

Artikel nr: 12810 Mätman knapplogger Startkit

Tillbehör

Artikel nr: 12800 Mätman knapplogger, 3-pack, -40°C - +85°C

Teknisk data

Arbetsområde:	-40°C - +85°C
Noggrannhet:	±1°C från -30°C till +70°C ±1.3°C från -40°C till -30°C och från +70°C till +85°C
Minneskapacitet:	2048 tidsstämlade mätningar
Programvara:	Mätman Kontroll 5
Mätintervall:	Steglös mellan 1 till 255 minuter
Kapslingsklass:	IP56
Storlek:	17,35 x 5,89 mm

Vi reserverar oss för ändringar i tekniska data och utförande

Starta mätning

Anslut Mätman adapter till PC:ns USB-port.

Sätt i knapploggern i adaptern.

Det kommer upp en ruta med frågan vill du starta en mätning. Välj Ja.

Loggningen är startad. Ta bort knappen och placera den i/på mätobjektet.

Stoppa mätning

Anslut Mätman adapter till PC:ns USB-port. Sätt i knapploggern i adaptern.

Det kommer upp en ruta med välj mätobjekt. Välj flik, grupp och objekt mätningen avser.

En extrafråga kommer upp i ett nytt bekräfta fönster svara ja om ok.

Det kommer upp ett nytt fönster där man kan välja om man vill starta ny mätning eller inte.

Vid nej ta ur knapploggern från adaptern tills ny mätning ska göras



User Manual for Mätman Button Logger

Mätman Button Logger

Part no: 12810 Mätman Button Logger Startkit

Accessory

Part no: 12800 Mätman Button Logger, 3 pack, -40°C - +85°C

Technical data

Temperature range:	-40°C - +85°C
Accuracy:	±1°C from -30°C to +70°C ±1.3°C from -40°C to -30°C and from +70°C to +85°C
Memory capacity:	2048 time stamped measurements
Software:	Mätman Check 5
Measurement interval:	Continuous between 1 to 255 minutes
Protection class:	IP56
Size:	17.35 x 5.89 mm

Changes of technical data and design are reserved.

Start measurement

Connect the Mätman adapter to the PC's USB port. Insert the button logger into the adapter. A dialog window with the question "Do you want to start a measurement" will appear. Select Yes. The logging is started. Remove the button and place it in/on the object to be measured.

Stop measurement

Connect the Mätman adapter to the PC's USB port. Insert the button logger into the adapter. A dialog window will appear. Select tab, group and the object the measurement refers to. An additional confirmation window will appear. If OK, select Yes. A new window will appear where you have the option to start a new measurement. If No, remove the button logger from the adapter.

